


# STEAKS

## TANK TOP SIZE GUIDE



Ref	HOW TO MEASURE? (in cm)	XXS	XS	S	M	L	XL	XXL
T3	Spread collar open and measure along top edge from collar point to collar point	44.3	45.7	47.1	48.5	49.9	51.3	52.7
T6	Straight across neck	15.2	15.8	16.4	17	17.6	18.2	18.8
T17	Individual Shoulder Width: Seam to Seam	11.7	12.3	12.9	13.5	14.4	15.3	16.2
T19	Hi-Chest	29.5	31.5	33.5	35.5	37.5	39.5	41.5
T22	below bottom of armhole from edge to edge	37.5	40	42.5	45	47.5	50	52.5
T24	Straight across at bottom of garment, edge to edge	29.5	32	34.5	37	39.5	42	44.5
T29	From front neck seam / edge, excluding collar and stand, to bottom edge of garment	35.3	36.2	37.1	38	38.9	39.8	40.7
T34	Armhole	43.1	44.4	45.7	47	48.3	49.6	50.9
T61	Back Length from Neck Seam	37.25	38.5	39.75	41	42.25	43.5	44.75
T63	Hi-Back	27.5	29.5	31.5	33.5	35.5	37.5	39.5

Creating a shirt is a manual art, dimensions may vary from few millimeters...

